



Rainbow Dyeing using Lanaset/Sabreset Dyes

Please read directions carefully before starting.

PO Box 14 • Somerset, MA 02726
orders 1-800-2-BUY-DYE
technical support 508-676-3838
fax 508-676-3980
e-mail • promail@prochemical.com
www.prochemical.com

Use Lanaset/Sabreset Dyes to produce rainbow or variegated dyed wool, silk, angora, mohair and nylon. It is important to do samples before working on a large project. For additional information visit our web site at www.prochemical.com.

- ✦ Wear rubber gloves, apron or old clothes and cover work area with newspapers.
- ✦ Dye utensils should never be used for food preparation.

Supplies

Lanaset/Sabreset dye
Synthrapol
Citric Acid Crystals or white vinegar

Procedure

1. Make the acid soak solution. Please read the three methods below then choose the one that best suits your application needs. Soak the fiber for at least 30 minutes, in one of the solutions below.

NOTE: Soak Solution can be kept indefinitely in closed container and can be reused to soak more fiber.

Method #1

1 gallon (4 liters) 95°F (35°C) water
6 Tbl (105 gm) Citric Acid Crystals
2 tsp (10 ml) Synthrapol

Method #2

3 quarts (3 liters) 95°F (35°C) water
4 cups (1 liter) white vinegar
2 tsp (10 ml) Synthrapol

2. Make the dye paint. Decide if you want a pale, medium or dark value. Measure the dye powder amount, according to the chart below, into a clean dry 1 cup (250 ml) measure. Dissolve the dye powder with 1 cup (250 ml) of boiling water and set aside until cool.

	Pale	Medium	Dark	Black
Dye powder	¼ tsp (0.75 gm)	1 tsp (2.5 gm)	2 tsp (5 gm)	4 tsp (10 gm)

3. Apply the dye paint. While wearing rubber gloves, squeeze out any excess acid soak solution from the fiber. Lay fiber (yarn or fleece) on a length of plastic wrap. Apply the dye solution with a sponge brush, squeeze bottle, syringe, or by dipping the fiber into the dye paint. Work the dye solution into the yarn or fleece with your gloved fingers to insure thorough saturation.

NOTE: Leftover dissolved dye can be stored for a minimum of 6 months.

It is handy to have a bucket of clear water next to your working area to rinse your hands between color changes. Obtain a fluid color gradation by overlapping one or two colors to produce a third color. Be careful not to apply so much dye that color drips from the fiber, as colors run together during the steam set process. Wrap the fiber with the plastic wrap. If you are dyeing silk, put this wrapped bundle aside for 30 minutes. This 30 minute rest yields darker colors because the dye penetration improves.

4. Set the dye. Place the plastic wrapped fiber on a stainless steel leaved vegetable steamer. Place the steamer in a stainless steel, enamel, or Pyrex pot with water in the bottom. Water should not touch the bottom of the vegetable steamer basket. Place the pot on a burner and cover. Steam for 30 minutes, measuring the time after the water begins to boil. After 30 minutes, turn the heat off and allow the fiber to cool to room temperature. Remove the fiber and rinse thoroughly in warm water. Squeeze out excess water and air dry.